

## Spray Tanning Instructions

1



**Remove  
Jewelry**



**Put on haircap –  
leave ears and  
hairline exposed**



**Apply blending cream  
to hands and feet  
including nails**

**NOTE:** The FDA recommends wearing protective eyewear, nose filters, ear plugs, lip balm, and undergarments. Ask the salon staff for details.

2



**STEP 1**



**STEP 2**



**STEP 3**



**STEP 4**

**Wave your hand in front of the green light to start.  
Audio instructions will walk you through 4 easy poses.**

3

**Remove blending cream.  
Wait 4-6 hours before getting wet, like working out or showering.  
Keep your skin moisturized for a longer lasting tan.**